ASSEMBLY INSTRUCTIONS FOR

HARVEST TAPERED DRUM PENDANT ITEM # 4002-12/16/18

Please read and save these assembly instructions:

Be careful when unpacking the lamp since the wires are connected (if the wires are pulled out of their connectors, it may result in a bad connection.)

1.CAUTION: Once being mounted,do not pull on lamp as this may cause injury to persons and damage to the lamp and mounting surface. To reduce risk of such injury or damage, mount on a surface that is mechanically solid.

2.Fasten mounting hardware to wooden ceiling support beams only. Do not mount to plasterboard.

3.Through the socket of the wire (D) to shade (E) and screw the socket ring(F) onto shade holder.

4.Use only with one type A Max 150W bulb (bulbs not included).

NOTE: For mounting to a solid ceiling, screw hooks directly to the ceiling.

PARTS INCLUDED:
A.2 Screw Anchors
B.2 Screws
C.2 Hangers
D.Socket
E.Shade
F.Socket ring
G.Bulb

WARNING:Do not use cord in wet conditions.



CAUTION:

Many people are choosing to use energy efficient CFL light bulbs. CFL's vary in size based on manufacturer, features, and wattage. Some CFL bulbs may change the functionality of the lamp. For example: if this lamp has a low/high/off function or 3-way switch, then when using the CFL bulb on the low setting the bulb may either "flicker" or not work. We recommend only using at the “high” level.

IMPORTANT SAFETY INSTRUCTION

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. Do not alter the plug in any way.

Adesso®
SHAPING THE FUTURE OF HOME DESIGN

21 Penn Plaza Suite 909, New York, New York 10001
Tel: (212) 736-4440 Fax: (212) 736-4806
www.adessohome.com